



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		63828	HOUSING, FLYWHEEL	1		
2		63833	COVER, FLYWHEEL HOUSING	1		
3	10	20031	SCREW, COVER TO FLYWHEEL H	3		
3	10	28635	SCREW, COVER TO FLYWHEEL H	1		
4	13	26992	LOCKWASHER, COVER SCREW	4		
5	38	47520	SERIAL PLATE	1		
6	10	28642	SCREW, SERIAL PLATE ATTACH	4		
7	10	34353	SCREW, FLYWHEEL HOUSING T	5		
8	10	63826	SCREW, FLYWHEEL HOUSING T	2		