

| Parts List | | | | | Qty | Comment | Footnote |
|------------|-------|----------|-----------------------------|---|--------------------------|---------|----------|
| Ref | Class | Part | Description | | | | |
| 1 | 57 | 74270 | V-BELT, STEERING PUMP | 1 | | | |
| 2 | | 73873 | PULLEY, STEERING PUMP | 1 | | | |
| 3 | | 49684 | BRACKET, PUMP MOUNTING | 1 | | | |
| 4 | 10 | 32132 | SCREW, STEERING PUMP TO BF | 1 | | | |
| 4 | 10 | 40001203 | SCREW, STEERING PUMP TO BF | 1 | | | |
| 5 | 13 | 35048 | LOCKWASHER, STEERING PUMP | 1 | | | |
| 5 | 13 | 40024008 | LOCKWASHER, STEERING PUMP | 1 | | | |
| 6 | 23 | 90523 | SPACER, STEERING PUMP SCRE | 1 | | | |
| 7 | 10 | 47651 | SCREW, BRACKET TO CYLINDER | 2 | | | |
| 8 | 13 | 32993 | LOCKWASHER, BRACKET SCREW | 2 | | | |
| 9 | 12 | 30315 | WASHER, BRACKET SCREW (FO | 1 | | | |
| 10 | 11 | 86317 | NUT, STEERING PUMP STUD (NI | 1 | | | |
| 10 | 11 | 90517 | NUT, STEERING PUMP STUD (M | 1 | | | |
| 11 | | 77912 | OIL COOLER | 1 | | | |
| 12 | 54 | 32781 | CLAMP, OIL COOLER TO BRACK | 2 | | | |
| 13 | 54 | 64324 | CLAMP, HOSE ATTACHING TO O | 2 | | | |
| 14 | | 49748A | BRACKET ASSEMBLY, OIL COOL | 1 | | | |
| 15 | | 49735 | BRACKET, OIL COOLER MOUNT | 1 | | | |
| 16 | 10 | 20359 | SCREW, OIL COOLER MOUNTING | 1 | | | |
| 17 | 11 | 68411 | NUT, MOUNT BRACKET SCREW | 1 | | | |
| 18 | 22 | 37760 | ELBOW, OIL COOLER | 2 | | | |
| 19 | 10 | 48424 | SCREW, BRACKET TO ENGINE | 2 | | | |
| 20 | 13 | 35048 | LOCKWASHER, BRACKET SCREW | 2 | | | |
| 21 | 12 | 20572 | WASHER, BRACKET SCREW | 2 | | | |
| 22 | | 85011A | BRACKET ASSEMBLY, PUMP | 1 | SERIAL 05163434-09999999 | | |
| 23 | 10 | 26487 | SCREW, PUMP BRK. TO MOUNT | 2 | SERIAL 05163434-09999999 | | |
| 23 | 10 | 40001194 | SCREW, PUMP BRK. TO MOUNT | 2 | SERIAL 05163434-09999999 | | |
| 24 | 13 | 40024008 | LOCKWASHER, PUMP BRACKET | 2 | SERIAL 05163434-09999999 | | |
| 25 | 23 | 90520 | SPACER, PUMP ASSEMBLY BRAI | 2 | SERIAL 05163434-09999999 | | |

