



20188

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		92892	ADAPTER, SILENCER (TOP)	1	USE WITH AIR SILENCER	14
2		96450	ADAPTER, SILENCER (BOTTOM)	1	USE WITH AIR SILENCER	14
3	10	93467	SCREW, SILENCER ADAPTER (7.	4	USE WITH AIR SILENCER	
4		97514A 2	BRACE ASSEMBLY, SILENCER	1	USE WITH AIR SILENCER	
5		60577	MOUNT, SILENCER BRACE	1	USE WITH AIR SILENCER	
6	12	20346	WASHER, MOUNT STUD	1	USE WITH AIR SILENCER	
7	11	20088	NUT, MOUNT STUD	1	USE WITH AIR SILENCER	
8		92709A 1	FLAME ARRESTOR, CARBURETC	1	USE WITH AIR SILENCER	14
9	12	56184	WASHER, RUBBER	1	USE WITH AIR SILENCER	
10	23	93468	BUSHING, RUBBER WASHER	1	USE WITH AIR SILENCER	
11	12	86400	WASHER, SEALING	1	USE WITH AIR SILENCER	
12	11	20586	NUT, (.250-28), SILENCER ADAPT	1	USE WITH AIR SILENCER	
13	32	93314	HOSE, SILENCER	1	USE WITH AIR SILENCER	14
14	54	93313	CLAMP, SILENCER HOSE	2	USE WITH AIR SILENCER	
15		96287	ADAPTER, SILENCER HOSE	1	USE WITH AIR SILENCER	14
16	16	93360	STUD, FLAME ARRESTOR	1	USE WITH AIR SILENCER	
17	11	28941	NUT, JAM - FLAME ARRESTOR	1	USE WITH AIR SILENCER	
18	11	97468	NUT, FLAME ARRESTOR STUD	1	USE WITH AIR SILENCER	
19	54	96882	CLAMP, SILENCER HOSE	1	USE WITH AIR SILENCER	
20	16	91842	STUD, FLAME ARRESTOR	1	USE WITHOUT AIR SILENCER	
21	11	28941	NUT, JAM - FLAME ARRESTOR	1	USE WITHOUT AIR SILENCER	
22		85785A 2	FLAME ARRESTOR USE W/O AI	1	USE WITHOUT AIR SILENCER	
23	12	28927	WASHER, FLAME ARRESTOR ST	1	USE WITHOUT AIR SILENCER	
24		43560A 5	COVER, CARBURETOR	1	USE WITHOUT AIR SILENCER	
24		15414A 7	COVER, CARB. (USE W/CORRUC	1	USE WITHOUT AIR SILENCER	
25	12	86400	WASHER, SEALING	1	USE WITHOUT AIR SILENCER	
26	11	20586	NUT, (.250-28), FLAME ARRESTO	1	USE WITHOUT AIR SILENCER	
27	37	99117	DECAL, HORSEPOWER	1		
28	32	93315 12	HOSE, VENT - CARBURETOR (11	2		
28	32	15894 18	HOSE, Breather (CORRUGATED)	2		
29	54	53101	CLAMP, VENT HOSE	4		
30		47957	CONNECTOR, VENT HOSE TO RI	2		
31	25	59987	GROMMET, ROCKER COVER	2		
-		85785A 3	CONVERSION ASSEMBLY	1		