



20195

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	737	6523	PISTON AND PISTON PIN ASSEM	8		
2	737	6615	PISTON AND PISTON PIN ASSEM	AR		
2	39	67127	RING SET, PISTON (STANDARD)	8		
2	39	67128	RING, PISTON (.030 O.S.)	AR		
3	23	85721	BEARING UNIT, CRANKSHAFT (S	4		
3	23	85685	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85723	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85724	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85725	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85686	BEARING UNIT, CRANKSHAFT M	1		
4	23	85689	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85688	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85689	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85690	BEARING UNIT, CRANKSHAFT M	AR		
5	17	35312	PIN, Dowel, REAR BEARING CAP	1		
6	26	14756	SEAL, REAR BEARING CAP	1		4
7	230	5534	FLYWHEEL	1		
8	10	49845	SCREW, (.437-20 x 1.00), FLYWHE	6		
10		47607A 1	DRIVE PLATE, FLYWHEEL	1		
11	10	35091	SCREW, (.375-16 x 1.00), DRIVE F	6		
12	13	35048	LOCKWASHER, (.375), DRIVE PL	6		
13	614	3553	CONNECTING ROD	8		
14	10	52192	BOLT, CONNECTING ROD CAP	16		
15	11	37493	NUT, (.375-24), CONNECTING R	16		
16	23	85726	BEARING SET, Conn Rod (Standa	8		
16	23	85727	BEARING SET, Conn Rod (.001 Ur	AR		
16	23	85728	BEARING SET, Conn Rod (.002 Ur	AR		
16	23	85691	BEARING SET, Conn Rod (.010 Ur	AR		
16	23	85729	BEARING SET, Conn Rod (.020 Ur	AR		
17	429	6612	CRANKSHAFT	1		
18	28	34466	KEY, CRANKSHAFT PULLEY AND	2		
-	27	65184A88	ENGINE GASKET SET	1		