



BREAKDOWN OF WATER PUMP



PLASTIC BODY



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A32	WATER PUMP ASSEMBLY	1		
1A	46	72774	BODY, WATER PUMP (PLASTIC)	1		
2		87631	COVER, WATER PUMP	1		
3	10	28642	SCREW, WATER PUMP SLEEVE	4		
4	10	63328	SCREW, COVER TO BODY	5		
5	12	20084	WASHER, COVER TO BODY SC	5		
6	27	94915	GAASKET, COVER TO OUTER V	1		
7		94916	WEAR PLATE	1		
8	27	94914	GASKET, BODY TO WEAR PLA	2		
9	19	59504	PLUG, IMPELLER	1		
10	47	59362A 1	IMPELLER ASSEMBLY	1		
11	26	56662	KEY, IMPELLER DRIVE	1		
12		94576	WEAR PLATE	1		
13	25	37340	"O" RING, PUMP HOUSING	AR		
13	25	94288	QUAD SEAL, PUMP HOUSING	AR		
14	46	94913A 1	PUMP HOUSING	1		
15	26	90562	OIL SEAL, WATER PUMP SH/	2		
16	30	72961	BALL BEARING, WATER PUM	2		
17		59501	SHAFT, WATER PUMP	1		
18	53	23720	RING, SNAP - BALL BEARING	1		
19	26	72785	OIL SEAL, WATER PUMP SH/	1		
20		47530	HUB, WATER PUMP PULLEY	1		
21		73798	PULLEY, WATER PUMP	1		
22		58265	CLAMPING RING, PUMP PULLEY	1		
23	10	47277	SCREW, PULLEY TO WATER PU	4		
24	13	39107	LOCKWASHER, WATER PUMP P	4		
25	32	72837	HOSE, WATER PUMP TO OIL CO	1	- STERN DRIVE (WITH POWER	
26	54	32780	CLAMP, WATER PUMP HOSE	2	- STERN DRIVE (WITH POWER	
27		62711	STA-STRAP, HOSE ATTACHING	1	- STERN DRIVE (WITH POWER	
28		47489A 1	BRACKET, WATER PUMP	1		
29	10	47461	SCREW, WATER PUMP BRACKE	1		
30	13	35048	LOCKWASHER, WATER PUMP B	1		
30A	12	79643	WASHER, WATER PUMP BRACK	1		
30A	23	57369	SPACER, WATER PUMP BRACKE	OPT		
31	10	48948	SCREW, WATER PUMP BRACKE	1		
32	13	32993	LOCKWASHER, WATER PUMP B	1		
33	12	30315	WASHER, WATER PUMP BRACK	1		
34	10	34354	SCREW, WATER PUMP BRACKE	1		
35		77640	BRACE, WATER PUMP ADJUSTI	1	- STERN DRIVE	
35		64177	BRACE, WATER PUMP ADJUSTI	1	- STERN DRIVE	
36	10	26785	SCREW, BRACE TO BRACKET	1	- STERN DRIVE	