



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		71317A 8	STEERING PUMP ASSEMBLY, PC	1		
1		90507A 1	STEERING PUMP ASSEMBLY, PC	1		
2		38333	CAP, FILLER - PUMP	1		
3	32	65929	HOSE, RETURN - POWER STEEF	1		
3	32	65231	HOSE, RETURN - POWER STEEF	1		
4	54	35830	CLAMP, HOSE TO STEERING PU	3		
5	32	55116	HOSE, PRESSURE - POWER STE	1		
5	32	90494	HOSE, PRESSURE - POWER STE	1		
6		57969	CYLINDER, BOOSTER - POWER :	1		
7		26059	CAP, RUBBER - BOOSTER CYLIN	1		
8	32	57633	TUBE, EXTENDING - POWER STI	1		
9	32	57634	TUBE, RETRACTING - POWER S	1		
10		52779A 2	VALVE, POWER STEERING	1		
11	22	67305	FITTING, GREASE - POWER VAL	1		
12	16	55109	STUD, ADAPTOR - POWER STEE	1		
13	10	37612	SCREW, CLAMPING (1 1/4")	1		
14	13	37459	LOCKWASHER, CLAMPING SCRE	1		
15	23	60652	SLEEVE, ADJUSTING - CABLE GL	1		
16		64414	GUIDE, CABLE GUIDE TUBE	1		
17	23	60773	SLEEVE, CABLE GUIDE TUBE	1		
18		55110	ADAPTOR, CABLE GUIDE TUBE (1		
19	13	20897	LOCKWASHER, DUAL ADAPTOR	1		
20	11	55111	NUT, DUAL ADAPTOR TO POWE	1		
21	32	55112	TUBE, CABLE GUIDE	1		
22	12	37985	WASHER, CABLE GUIDE TUBE A	2		
23	11	37984	NUT, CABLE GUIDE TUBE AND M	2		
24		57286	BRACKET, MOUNTING - TRANSC	1		
25	10	31832	SCREW, MOUNTING BRACKET T	2		
26	13	31848	LOCKWASHER, MOUNTING BRA	2		
27	10	57968	SCREW, ADJUSTING - MOUNTIN	1		
28	13	37459	LOCKWASEHR, ADJUSTING SCR	1		
29	11	24883	NUT, ADJUSTING SCREW	1		
30	12	20959	WASHER, VALVE ADAPTOR STU	1		
31	11	28040	NUT, VALVE ADAPTOR STUD	1		
33		57971	TUBE, MOUNTING - BOOSTER R	1		
34	11	55983	NUT, JAM - MOUNTING TUBE	1		
35		57970	EXTENSION - CYLINDER BOOSTI	1		
36		66626	ADAPTOR, ROD END	1		
37	17	52798	PIN, CLEVIS - STEERING CABLE	2		
38	18	46350	COTTER PIN, CLEVIS PIN RETAI	2		