

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	57	74270	V-BELT, STEERING PUMP	1		
2		73873	PULLEY, STEERING PUMP	1		
3		49684	BRACKET, PUMP MOUNTING	1		
4	10	32132	SCREW, STEERING PUMP TO BF	1		
4	10	40001203	SCREW, STEERING PUMP TO BF	1		
5	13	35048	LOCKWASHER, STEERING PUMP	1		
5	13	40024008	LOCKWASHER, STEERING PUMP	1		
6	23	90523	SPACER, STEERING PUMP SCRE	1		
7	10	47651	SCREW, BRACKET TO CYLINDER	2		
8	13	32993	LOCKWASHER, BRACKET SCREW	2		
9	12	30315	WASHER, BRACKET SCREW (FO	1		
10	11	86317	NUT, STEERING PUMP STUD (NI	1		
10	11	90517	NUT, STEERING PUMP STUD (M	1		
11		77912	OIL COOLER	1		
12	54	32781	CLAMP, OIL COOLER TO BRACKE	2		
13	54	64324	CLAMP, HOSE ATTACHING TO O	2		
14		49748A	BRACKET ASSEMBLY, OIL COOLI	1		
15		49735	BRACKET, OIL COOLER MOUNT	1		
16	10	20359	SCREW, OIL COOLER MOUNTING	1		
17	11	68411	NUT, MOUNT BRACKET SCREW	1		
18	22	37760	ELBOW, OIL COOLER	2		
19	10	48424	SCREW, BRACKET TO ENGINE	2		
20	13	35048	LOCKWASHER, BRACKET SCREW	2		
21	12	20572	WASHER, BRACKET SCREW	2		
22		85011A	BRACKET ASSEMBLY, PUMP	1	SERIAL 05163434-09999999	
23	10	26487	SCREW, PUMP BRK. TO MOUNT	2	SERIAL 05163434-09999999	
23	10	40001194	SCREW, PUMP BRK. TO MOUNT	2	SERIAL 05163434-09999999	
24	13	40024008	LOCKWASHER, PUMP BRACKET	2	SERIAL 05163434-09999999	
25	23	90520	SPACER, PUMP ASSEMBLY BRAI	2	SERIAL 05163434-09999999	

