



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		44187A 1	HOUSING, FLYWHEEL	1	
1A	19	12304	PLUG, TIMING WINDOW	1	
2		14043A 5	COVER ASSEMBLY, FLYWHEEL H	1	
3		87690	SEAL, FLYWHEEL HOUSING CO	1	
4	27	86015	GASKET, FLYWHEEL HOUSING	1	2
5	10	41508	SCREW, COVER TO FLYWHEEL	2	
5	10	98253	SCREW, COVER TO FLYWHEEL	4	
5	10	49668	SCREW, COVER TO FLYWHEEL	1	
6	13	26992	LOCKWASHER, COVER SCREW	5	
7	10	37612	SCREW, FLYWHEEL HOUSING	1	
7	10	47688	SCREW, FLYWHEEL HOUSING	2	
8	13	35048	LOCKWASHER, FLYWHEEL HOU	7	
9	12	20572	WASHER, FLYWHEEL HOUSING	1	
10	54	78945	J CLAMP, FLYWHEEL HOUSING	1	
11	16	64066	STUD, FLYWHEEL HOUSING (2-1	1	
12	11	32219	NUT, FLYWHEEL HOUSING STUI	1	