



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A50	WATER PUMP ASSEMBLY	1		
2	46	72774A40	BODY	1		
3		87631A 4	COVER	1		
4	10	73275	SCREW (2-7/8")	2		
4	10	99347	SCREW (3-3/4")	3		
5	12	20084	WASHER	5		
6	27	805215 1	GASKET	1		
7		94916	OUTER WEAR PLATE	1		
8	27	94914	GASKET	2		
9	19	59504	PLUG	1		
10	47	59362 1	IMPELLER	1		
11		94576	INNER WEAR PLATE	1		
12	25	94288	QUAD RING	1		
13	46	94913A 2	PUMP HOUSING ASSEMBLY	1		
14	26	90562	OIL SEAL	2		
15	30	72961	BALL BEARING	2		
16		59501A 1	SHAFT	1		
17	53	23720	SNAP RING	1		
18	26	72785	OIL SEAL	1		
19		47530	HUB	1		
20		52822T	PULLEY	1		
21	10	47277	SCREW (3/4")	4		
22	13	39107	LOCKWASHER	3		
23	11	21908	NUT	3		
24		89535T 1	BRACKET	1		
25	10	34353	SCREW (1")	2		
26	13	35048	LOCKWASHER	2		
27	12	34714	WASHER	1		
28		89609 1	BRACE	1		
29	10	26487	SCREW (1")	1		
30	13	35048	LOCKWASHER	1		
31	12	34714	WASHER	1		
32	10	35786	SCREW (1")	1		
33	13	35048	LOCKWASHER	1		
34	11	46335	NUT	1		
35	57	13457T	BELT	1		