



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		860256A 1	HOUSING ASSEMBLY-THERMOS	1	5.7L/LX ALPHA	
1		806235A 1	HOUSING ASSEMBLY-THERMOS	1	350 MAGNUM ALPHA	
2	22	32803	PLUG-PIPE (3/8 IN.)	2		
3	27	806871	GASKET-THERMOSTAT	1		3
4	27	53045 1	GASKET	1		3
5		807252 2	THERMOSTAT (160 DEG.)	1		
6	23	806922	SLEEVE	1		
7	10	98508	SCREW (3/8-16 X 3 IN.)	2	5.7L/LX ALPHA	
7	10	98794	SCREW (3/8-16 X 1 IN.)	2	350 MAGNUM ALPHA	
8	32	808033	HOSE-THERMOSTAT HOUSING	1		
9	32	860089	HOSE-POWE EXTENDER TO POW	1		
10	32	807661	HOSE-POWER STEERING COOL	1		
11	54	815504222	CLAMP-HOSE	5		
12	54	815504212	CLAMP-HOSE	1		
13	32	87108	HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	860144	HOSE-THERMOSTAT HOUSING	1		
16	32	807697	HOSE-THERMOSTAT HOUSING	1		
17	54	815504220	CLAMP-HOSE	4		
18	54	47715	CLIP	1		
19	11	29250	NUT (5/16-24)	1		
20		12552	LIFTING EYE	1	5.7L/LX ALPHA	
21		807292T	COOLER-POWER STEERING OIL	1		
22		805546A 2	BRACKET-TRANSMISSION OIL C	1		
23		77223 3	PAD	1		
24	54	815504224	CLAMP	1		
25	10	816585	SCREW (5/16-18 X 7/8 IN.)	1		
26		860315A 1	EXTENDER-HOSE	1		
27	22	806608A 1	PLUG-DRAIN	2		
28	25	806609	QUAD RING	2		
29		48134	BRACKET	1	DESIGN I	
30	54	97862	CLAMP	1	DESIGN I	
31	10	54630	SCREW (5/16-24 X 5/8 IN.)	1	DESIGN I	
32	13	39107	LOCKWASHER (5/16 IN.)	1	DESIGN I	
33	11	22053	NUT (5/16-24)	1	DESIGN I	
34		860418T	BRACKET	1	DESIGN II	
35		860417T	CLAMP	1	DESIGN II	
36	12	35462	WASHER	1	DESIGN II	
37	11	72008	NUT	1	DESIGN II	
-	27	806871A96	GASKET SET-OVERHAUL	1	CONTENTS INDICATED BY FOO	