



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		97401A 8	FUEL PUMP	1		
2	27	34213	GASKET	1		5
3	10	34354	SCREW (1-1/2 IN.)	2		
4	13	35048	LOCKWASHER	2		
5		35373	MOUNTING PLATE	1		
6	27	34898	GASKET	1		5
7	10	35366	SCREW	2		
8		35377	PUSH ROD	1	(USE WITH FLAT LIFTERS)	6,7
8		821150	PUSH ROD	1	(USE WITH ROLLER LIFTERS)	8,9
9		89876A 3	BASE ASSEMBLY	1		
10	22	816133 1	FITTING	1		
11	22	32561	PIPE PLUG	3		
12		88641	MOUNTING BRACKET	1		
13	11	35814	NUT	2		
14	35	807172	FUEL FILTER/WATER SEPARATI	1		
15	22	33821	CONNECTOR	3	USE WITH 2 BBL. CARB.	
15	22	33821	CONNECTOR	2	USE WITH 4 BBL. CARB.	
16	22	43276	ELBOW	1	USE WITH 4 BBL. CARB.	
17	32	97326T	FUEL LINE	1		
18	32	96855T	FUEL LINE	1	(USE WITH 2 BBL. CARB.)	
18	32	821761T	FUEL LINE	1	(USE WITH 4 BBL. CARB.)	
19	32	73815 67	HOSE	1		
20		805367T	BRACKET	1		
21	10	37612	SCREW	1		
22	13	35048	LOCKWASHER	1		
23	23	91034	SPACER	1		
24	10	26486	SCREW	1		
25	13	35048	LOCKWASHER	1		
26	12	20553	WASHER	1		
27	23	15895	SPACER	1		
-	27	806871A96	GASKET SET-OVERHAUL	1	CONTENTS INDICATED BY FOO	