



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	806964A 3	STARTER MOTOR	1		
2	10	805343 2	SCREW	2		
3	11	806949	NUT (8MM)	1		
4	11	40021 1	NUT (5MM)	1		
5	85	79695	INSULATOR	1		
6	88	79023A91	FUSE ASSEMBLY (90 AMP)	1		
7	11	21825	NUT	1		
8		805884T	ALTERNATOR	1		
9	12	96457	PHENOLIC WASHER	1		
10	13	26996	LOCKWASHER	1		
11	11	79989	NUT (10-24)	1		
12	13	26992	LOCKWASHER	1		
13	11	94330	NUT (1/4-20)	1		
14		57908 11	TUBING	2		
15		85013T	BRACE	1		
16	10	98261	SCREW	1	(ALPHA ENGINES)	
16	10	26487	SCREW	1	BRAVO ENGINES	
17	13	35048	LOCKWASHER	1	BRAVO ENGINES	
18	10	29198	SCREW	1		
19	12	26168	WASHER	1		
20		15083T	BRACKET	1		
21	10	37612	SCREW (1-1/4")	2		
22	12	20553	WASHER	2		
21	10	34353	SCREW (1")	1		
22	12	20553	WASHER	1		
21	10	48424	SCREW (1-5/8")	1		
22	13	35048	LOCKWASHER	1		
23	12	46132	WASHER	1		
24	10	56743	SCREW (3-1/8")	1		
25	11	23161	NUT	1		