



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87290A 4	THERMOSTAT HOUSING ASSEM	1		
2	23	47511	SLEEVE, THERMOSTAT HOUSI	1		
3	22	32803	PIPE PLUG	2		
4	27	53045	GASKET, THERMOSTAT HOUSIN	1		4
5		59137	THERMOSTAT (143)	1		
6	27	47510	GASKET, THERMOSTAT	1		4
7	23	47508	SLEEVE, THERMOSTAT	1		
8	27	41812	GASKET, THERMOSTAT COVER	1		4
10		47441A 1	COVER, THERMOSTAT	1		
11	10	33389	SCREW, THERMOSTAT HOUSIN	2		
11	10	48130	SCREW, THERMOSTAT HOUSIN	2		
12	13	35048	LOCKWASHER, THERMOSTAT H	2		
13	22	98477A 2	TEE, THERMOSTAT HOUSING	1		
14	32	33220 70	HOSE, TEE TO EXHAUST ELBOW	2		
15	54	32780	CLAMP, HOSE ATTACHING	8		
16	32	87116	HOSE, THERMOSTAT COVER TC	1		
17	32	87117	HOSE, THERMOSTAT COVER TC	1		
18	54	47715	CLIP, HOSE ATTACHING	1		
19	32	88794	HOSE, THERMOSTAT HOUSING	1	W/POWER STEERING	
20	32	96246A 4	HOSE, FLUID COOLER TO HOUS	1	W/POWER STEERING	
21	54	32780	CLAMP, HOSE ATTACHING	4	W/POWER STEERING	
22		99356A 2	COOLER, POWER STEERING FLU	1	W/POWER STEERING	
23		65970	BRACKET, COOLER	1	W/POWER STEERING	
24	10	41408	SCREW, BRACKET	1	W/POWER STEERING	
25	10	34353	SCREW, BRACKET TO ENGINE	1	W/POWER STEERING	
26	12	46132	WASHER, BRACKET SCREW	1	W/POWER STEERING	
27	32	98033A 3	HOSE, THERMOSTAT HOUSING	1	W/O POWER STEERING	
28	54	32780	CLAMP, HOSE ATTACHING	2	W/O POWER STEERING	
29	32	87108	HOSE, THERMOSTAT HOUSING	1		
30	54	87268	CLAMP, HOSE ATTACHING	2		
31		12552	LIFTING EYE (USE 10-48130)	1		