



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY	1		
2	16	98798	1 STUD	1		
3		12381	1 RETAINER	1		
4	23	98828	SPACER	1		
5	10	53167	SCREW	1		
6	18	32857	COTTER PIN	1		
7	24	98880	SPRING	1		
8	12	56720	WASHER	2		
9	23	98820	SPACER (USE WHERE APPLICAE	1		
10	12	35462	WASHER	5		
11	11	13438	NUT	2		
12	16	96112	STUD	1		
13	11	63341	TEE NUT	1		
14		13898	1 SHIFT LEVER	1		
15	10	13743	SHOULDER SCREW	1		
16	17	68402	SHOULDER PIN	1		
17	18	21071	COTTER	1		
18	23	806981	SPACER	3		
19	12	35462	WASHER	3		
20	11	64015	NUT	3		