



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		806816T	BRACKET/LIFTING EYE(REAR)	1		
2	10	98261	SCREW	2		
3		26079A 2	PLATE	1		
4	10	15001	SCREW	4		
5		97257A 1	WATER TEMPERATURE SENDEI	1		
5		49734A 1	WATER TEMPERATURE SENDEI	OPT	(DUAL STATION)	3
6		815425	OIL PRESSURE SENDER	1		
6		37293	OIL PRESSURE SENDER	OPT	(DUAL STATION)	3
7	13	26996	LOCKWASHER	2		
8	11	68219	NUT	2		
9	22	805059	BUSHING	1		
10	22	806705	Y-FITTING	1		
11		806612T	KNOCK SENSOR	1		
12		805218T	COOLANT TEMPERATURE SENS	1		
13	22	36382	PIPE PLUG	1		
14		805592A 1	CONNECTOR	1		
15	87	805605A 1	PRESSURE SWITCH	1		
16	22	805328 1	ELBOW (90 degrees)	1		
17		816492A 6	AUDIO WARNING SYSTEM	1		
18	84	95084A 9	WIRE	1		
19	88	79091	FUSE	1		
20	84	95084A10	WIRE	1		