



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|-------------------------------------|-----|-------------|----------|
| 1 | | 806235A 1 | THERMOSTAT HOUSING ASSEM | 1 | | |
| 2 | 22 | 32803 | PIPE PLUG | 2 | | |
| 3 | 27 | 806871 | GASKET | 1 | | 1 |
| 4 | 27 | 53045 1 | GASKET | 1 | | 1 |
| 5 | | 807252 2 | THERMOSTAT | 1 | | |
| 6 | 23 | 806922 | SLEEVE | 1 | | |
| 7 | 10 | 98794 | SCREW | 2 | | |
| 8 | 54 | 815504220 | CLAMP | AR | | 4 |
| 9 | 32 | 88795 2 | HOSE-oil cooler to sea pump | 1 | | |
| 10 | 32 | 806856 | HOSE-oil cooler to thermostat housi | 1 | | |
| 11 | 32 | 806825 | HOSE-thermostat housing to water | 1 | | |
| 12 | 54 | 815504232 | CLAMP | 2 | | |
| 13 | 32 | 806635 1 | HOSE-thermostat housing | 1 | (PORT) | |
| 14 | 32 | 806636 1 | HOSE-thermostat housing | 1 | (STARBOARD) | |
| 15 | 54 | 47715 | CLIP | 1 | | |
| 16 | 11 | 29250 | NUT | 1 | | |
| 17 | | 807292T | COOLER | 1 | | |
| 18 | 54 | 816398 | CLAMP | 1 | | |
| 19 | 32 | 17435 79 | HOSE-water pump to drive unit | 1 | | |
| - | 27 | 806988A96 | GASKET SET-O'verhaul | 1 | | |