



| Parts List | | | | | | |
|------------|-------|-----------|-----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 807323A 5 | BOX-ELECTRICAL COMPONENTS | 1 | | |
| 2 | | 806762A 1 | VELCRO KIT | 1 | | |
| 3 | | 806611T | MODULE ASSEMBLY-KNOCK | 1 | | |
| 4 | 11 | 64015 | NUT (1/4-20) | 1 | | |
| 5 | 89 | 96054 | SOLENOID ASSEMBLY-STARTEF | 1 | | |
| 6 | 13 | 26395 | LOCKWASHER (#8) | 2 | | |
| 7 | 11 | 26419 | NUT (#8-32) | 2 | | |
| 8 | 13 | 26392 | LOCKWASHER (1/4 IN.) | 2 | | |
| 9 | 11 | 94330 | NUT (1/4-20) | 2 | | |
| 10 | 12 | 35462 | WASHER | 2 | | |
| 11 | 11 | 64015 | NUT (1/4-20) | 2 | | |
| 12 | 85 | 97861 | INSULATOR-STARTER SOLENOI | 1 | | |
| 13 | 88 | 11178 | BREAKER-CIRCUIT (50 AMP) | 1 | | |
| 14 | 10 | 45862 | SCREW (#10-32 X 7/8 IN.) | 2 | | |
| 15 | 11 | 61356 | NUT (#10-32) | 2 | | |
| 16 | 13 | 26396 | LOCKWASHER (#10) | 2 | | |
| 17 | 11 | 68219 | NUT (#10-32) | 2 | | |
| 18 | | 805615A 2 | SCREW ASSEMBLY-THUMB | 1 | | |
| 19 | 10 | 24323 | SCREW-SET | 3 | | |
| 20 | 23 | 806381 | SPACER | 3 | | |
| 21 | 12 | 35462 | WASHER | 3 | | |
| 22 | 11 | 64015 | NUT (1/4-20) | 3 | | |
| 23 | | 861265T 1 | MODULE ASSEMBLY-ECM | 1 | | |
| 24 | 10 | 76596 | SCREW (1/4-20 X 1-1/4 IN.) | 4 | | |
| 25 | 12 | 20533 | WASHER | 4 | | |
| 26 | 11 | 805562 | NUT (#10-24) | 3 | | |
| 27 | | 805704 | FUSE (15 AMP) | 1 | | |
| 27 | | 805703 | FUSE (10 AMP) | 1 | | |
| 28 | | 807057 | RELAY-FUEL PUMP/IGNITION SY | 2 | | |
| 29 | | 805439T 3 | LID-ELECTRICAL BOX | 1 | | |