



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		809395	COVER-ROCKER (W/ OIL FILL HC)	1		
1		809396	COVER-ROCKER (W/O OIL FILL F)	1		
2	36	18710	CAP-OIL FILL	1		
3	10	17344	SCREW	8		
4	27	17467	GASKET-ROCKER COVER	2		3
5	25	52188	GROMMET	2		
6		97850	ELBOW (90 DEG.)	1		
7	32	861977	HOSE-PCV	1		
8	21	861476	VALVE-PCV	1		1
9	32	807498240	HOSE-BREATHER	1		
10	54	815504105	CLAMP	2		
11		807688T	TUBE-OIL FILL	1		
12		17339	PUSH ROD	16		
13		824317	VALVE-EXHAUST (STANDARD)	8		
13		824318	VALVE-EXHAUST (.030 O.S.)	AR		4
14		809992	VALVE-INTAKE (STANDARD)	8		
15	26	97664	SEAL-VALVE (INTAKE)	8		3
16	26	804507	SEAL-VALVE (EXHAUST)	8		3
17	24	48347	SPRING	16		
18		48348	CAP	16		
19	28	54797	KEY	32		
20		35329	ARM KIT-ROCKER	16		
21		35331	BALL UNIT	16		
22	11	34516	NUT	16		
23	938	803860T	HEAD ASSEMBLY-CYLINDER	2		
24	16	34522	STUD (.003 O.S.)	AR		4
24	16	34521	STUD (.013 O.S.)	AR		4
25	27	75611	GASKET	2		3
26	10	11968	BOLT (7/16-14 X 1-3/4 IN.)	16		
27	10	11967	BOLT (7/16-14 X 3 IN.)	4		
28	10	11966	BOLT (7/16-14 X 3-3/4 IN.)	14		
29	54	92850	CLAMP	1		
30	23	91034	SPACER	1		
31	10	37612	SCREW (3/8-16 X 1-1/4 IN.)	1		
-	27	75611A98	GASKET SET-ENGINE OVERHAU	1		