



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		26079A 2	PLATE KIT	1	
2	10	15001	SCREW (#8-16 X 7/8 IN.)	4	
3		807453T	BRACKET-HARNESS MOUNTING	1	
4	10	98261	SCREW (3/8-16 X 3/4 IN.)	2	
5		805368T	BRACKET-ELECTRICAL	1	
6	88	806950	BREAKER-CIRCUIT (50 AMP)	1	
7	10	68513	SCREW (#10-32 X 3/8 IN.)	2	
8	13	26996	LOCKWASHER (#10)	2	
9	10	57583	SCREW (#8-32 X 3/8 IN.)	2	
10	89	96158T	SOLENOID-STARTER	1	
11	13	26995	LOCKWASHER (#8)	2	
12	11	26419	NUT (#8-32)	2	
13	10	805564	SCREW (1/4-20)	2	
14	16	805459	STUD-MERCATHODE MOUNTING	1	
15	13	26992	LOCKWASHER (1/4 IN.)	2	
16	11	94330	NUT (1/4-20)	2	
17	85	97861	INSULATOR-STARTER SOLENOI	1	
18		861714T	BRACKET-ECU MOUNTING	1	
19	12	35462	WASHER	3	
20	11	64015	NUT	3	
21	10	28636	SCREW	3	
22	54	804351	CLIP-RELAY MOUNTING	2	6
23	54	804352	CLIP-FUSE BLOCK MOUNTING	1	6
24		807057T	RELAY	2	6
25	88	804638	FUSE-10 AMP MICRO	2	6
26	88	832969 15	FUSE-15 AMP MICRO	1	6
27		861927T 3	MODULE ASSEMBLY-ECM	1	1
28		861881	BRACKET-ELECTRICAL MOUNTING	1	1
29	10	73286	SCREW (1/4-20 X 1/2 IN.)	1	1