



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	805059	BUSHING-REDUCER	1		
2		815425T	SENDER-OIL PRESSURE	1		
2		37293T	SENDER-OIL PRESSURE (DUAL : OPT	1		5
3		806490T	SENDER-WATER TEMPERATUR	1		
3		49734	SENDER-WATER TEMPERATUR	OPT		5
4	13	26996	LOCKWASHER (#10)	2		
5	11	68219	NUT (#10-32)	2		
6	22	32974	FITTING-STRAIGHT (1/8"-27)	1		
7	87	805605A	SWITCH-OIL PRESSURE	1		
8		816492A	ALARM KIT	1		
9		805592A	CONNECTOR	1	(White Wire)	
9		830796A	CONNECTOR	1	(Black Wire)	
10		806612T	SENSOR-KNOCK	1		
11		805218T	SENSOR-COOLANT TEMPERATL	1		
12	22	806705	FITTING-Y	1		
13	84	95084A	CABLE ASSEMBLY	1		
14	88	79091	FUSE (20 AMP)	1		
15		805592A	CABLE ASSEMBLY	1		