



22806

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		863422T 1	BRACKET, Fuel Cooler	1		
2		807685T	INSULATOR, Base	1		
3		861156A03	FUEL PUMP / COOLER KIT	1		
4	22	807783A 1	FITTING ASSEMBLY, (90 Degree)	1		
5	25	805063	O-RING, (.301 x .070)	4		
6	22	808001A 1	FITTING ASSEMBLY	1		
7	25	805062	O-RING, (.530 x .082)	1		
8		865356T	COOLER, Fuel	1		
9	10	866114	SCREW, (.250-28) Special	1		
10	53	861414	RING, Retaining	1		
11		807979T	BRACKET	1		
12	11	29598	NUT, (.250-28)	2		
13		861126A 1	REGULATOR KIT, (43 PSI)	1		
14	35	805406	FILTER	1		
15	25	805531	O-RING, (.476 x .075)	1		
16	12	89302	WASHER, (.203 x .406 x .040)	2		
17	22	808002A 1	FITTING KIT	1		
18	12	36533	WASHER, (.328 x .562 x .0312) C	1		
19	10	808005	SCREW, (.250-20 x .500)	4		
20		26901 1	BUMPER, Rubber	8		
21		807930	INSULATOR, Cover	1		
22	32	864513001	HOSE ASSEMBLY, Fuel Cooler To	1		
23	26	863151	SEAL	1		
24	11	860069	NUT, (.375-16)	2		
25	32	806173 82	HOSE, (.58.00 Inches Bulk), Fuel Pr	1		
26	32	807954T	HOSE ASSEMBLY, Fuel Pressure F	1		
27	32	864152 1	HOSE ASSEMBLY, Fuel Filter To F	1		
28	10	852368	SCREW, (#10-24 x .750)	2		