



A= To Transom

1693

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	860089	1 HOSE, Molded, Power Steering to f	1		
2	32	807694	40 HOSE, (4.00 Inches), Fuel Cooler to	1	(Cut to Length)	
3	32	864578	HOSE, Drain Fitting to Check Valve	1		
4	32	864579	HOSE, Check Valve to Thermostat	1		
5	32	864703A	1 HOSE, Circulating Pump to Drain El	1		
6	32	864538	HOSE, Starboard Exhaust Elbow to	1		
7	32	863459	HOSE, Thermostat Exhaust to Starl	1		
8	32	863458	HOSE, Thermostat Housing to Port	1		
9	32	863611	HOSE, Sea Water Pump to Power :	1	(Bravo)	
10	32	807661	HOSE	1		
11	32	17435	79 HOSE, (96.00 Inches Bulk), Transo	1	(Alpha)	
12		861505	FITTING, Drain Tee	1		
13	21	862271A	1 CHECK VALVE	1		
14	32	864435	HOSE, Port Exhaust Elbow to Ther	1		
15	22	806926A	1 ELBOW KIT, Drain	2		
16	22	806608A	1 PLUG KIT, Blue	9		
17	25	32509	O-RING, (.489 x .070)	9		
18	22	860088	BUSHING	4		
19	22	46982	FITTING, (90 Degree), 90 Degree	1		
20	54	815504216	CLAMP, Worm Gear, Hose	4		
21	54	815504222	CLAMP, Worm Gear, Hose	11		
22	54	815504228	CLAMP, Worm Gear, Hose	4		
23		863841T	1 WATER TUBE, Brass	1	(Compact Hydraulic Steering)	
24	22	863804	FITTING, (.750-14), Barb	1		