

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		89876A	BASE ASSEMBLY, Fuel Filter/Water	1		
2	22	816133	FITTING	1		
3	22	32561	PLUG, Pipe (.250-18 Allen Head)	1		
4	22	33821	CONNECTOR	1		
5	22	808003	CONNECTOR	1		
6	22	807958	FITTING	1		
7	35	807172	FUEL FILTER, Fuel/Water Separat	1		
8		807956T	INSULATOR, Back	1		
9		807806T	INSULATOR, Cap	1		
10		807807T	INSULATOR, Base	1		
11		807918T	BRACKET, Fuel Filter Base	1		
12	11	45592	NUT, (.312-24)	2		
13	11	860069	NUT, (.375-16)	2		
14	32	807953T	FUEL LINE ASSEMBLY	1		
15	32	807954T	HOSE ASSEMBLY, Fuel Regulator	1		

