



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		<b>92497A 3</b>	<b>ALTERNATOR ASSEMBLY</b>	<b>1</b>	<b>(55 AMP)</b>	
1	390	7027	NUT	1		
2	390	7033	LOCKWASHER	1		
3	390	8637	PULLEY	1		
4	390	7004	FAN	1		
5		813969	SPACER	1		
6		813961	FRONT HOUSING	1		
7	390	7005	BALL BEARING	2		
8	10	813978A 1	SCREW	4		
9	390	7034	KEY	1		
10		813962	ROTOR	1		
11	390	7014	SLIP RING	1		
12		813963	STATOR	1		
13	390	7007	RETAINER	1		
14		813964	REAR HOUSING	1		
15	10	813975	THRU BOLT	4		
16		813966	DIODE BRIDGE	1		
17		813965	DIODE FIELD	1		
18	10	813981	SCREW	3		
19	11	813976	NUT	2		
20		813973	STRAP	1		
21	390	7021	NUT	5		
22		813971	COVER	1		
23	12	813984	WASHER	5		
24	390	7022	WASHER	2		
25		813972	CAPACITOR	1		
26	10	813982	SCREW	1		
27	10	813979	SCREW	2		
28	10	813983	SCREW	2		
29		813974	VOLTAGE REGULATOR	1		
30	12	813985	WASHER	2		
31	11	813977	NUT	2		
32	10	813980	SCREW	8		
33		813968	BRUSH ASSEMBLY	1		
34		813967	STRAP (D+)	1		
35	27	813970	GASKET	1		