


BREAKDOWN OF WATER PUMP



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	63450A 2	WATER PUMP ASSEMBLY, COMF	1	SERIAL 00000000-04178869	
1	46	73823A 7	WATER PUMP ASSEMBLY, COMF	1	SERIAL 04178870-09999999	
2		59155	COVER, WATER PUMP	1		
3	10	28635	SCREW, WATER PUMP COVE	6		
4	25	59712	"O" RING, WATER PUMP COVE	1		
5	19	59504	PLUG, IMPELLER	1		
6	47	59362A 1	IMPELLER ASSEMBLY	1		
7	28	56662	KEY, IMPELLER DRIVE	2		
8		59363A 1	CAM SEGMENT ASSEMBLY, W	1		
9	10	60777	SCREW, CAM SEGMENT ATTAI	1		
10		59503	WEAR PLATE	1		
11	23	47511	SLEEVE, WATER PUMP COVE	2		
12	26	23300	OIL SEAL, WATER PUMP SHAF	2		
13	30	20861	BALL BEARING, WATER PUMP	2	SERIAL 00000000-04178869	
13	30	72961	BALL BEARING, WATER PUMP	2	SERIAL 04178870-09999999	
14		59501	SHAFT, WATER PUMP	1		
15	53	23720	RING, SNAP - BALL BEARING R	1		
16	26	59564	OIL SEAL, WATER PUMP SHAF	1	SERIAL 00000000-04178869	
16	26	72785	OIL SEAL, WATER PUMP SHAF	1	SERIAL 04178870-09999999	
17		47530	HUB, WATER PUMP PULLEY	1		
18		59762	PULLEY, WATER PUMP	1	SERIAL 00000000-04501640	
18		73798	PULLEY, WATER PUMP	1	SERIAL 04501641-09999999	
18A		58265	CLAMP RING, WATER PUMP PUL	1	SERIAL 04501641-09999999	
19	10	20705	SCREW, PULLEY TO WATER PU	4	SERIAL 00000000-04501640	
19	10	33524	SCREW, PULLEY TO WATER PU	4	SERIAL 04501641-09999999	
20	13	39107	LOCKWASHER, WATER PUMP P	4		
21	57	39756	BELT, WATER PUMP	1	SERIAL 00000000-04501640	
21	57	74271	BELT, WATER PUMP	1	SERIAL 04501641-09999999	
22	22	32802	PLUG, PIPE - WATER PUMP	1		
23		47489	BRACKET, WATER PUMP	1		
24	10	34354	SCREW, WATER PUMP BRACKE	1		
25	13	35048	LOCKWASHER, WATER PUMP B	1		
26	10	48948	SCREW, WATER PUMP BRACKE	1		
26	10	47461	SCREW, WATER PUMP BRACKE	1		
27	13	32993	LOCKWAHER, WATER PUMP BR	2		
28	12	30315	WASHER, WATER PUMP BRACK	1		
29		47544	BRACE, WATER PUMP ADJUSTI	1		
30	10	34353	SCREW, ADJUSTING BRACE TO	1		
31	13	35048	LOCKWASHER, ADJUSTING BRA	1		
32	12	20572	WASHER, ADJUSTING BRACE S	1		
32	10	26785	SCREW, ADJUSTING BRACE TO	1		