



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805597A	1 BRACKET (TRANSMISSION)	2		
2	10	37269	SCREW (2")	2		
2	10	91903	SCREW (1 3/4")	2		
3	13	32993	LOCKWASHER	4		
4	10	57357	SCREW (2-1/4")	2		
4	10	37269	SCREW (2")	2		
5	13	32993	LOCKWASHER	2		
6	11	29553	NUT	2		
7		71128A	2 BRACKET (ENGINE)	2		
8	10	68101	SCREW (1-3/8")	1		
8	16	805357	STUD	5		
9	13	35048	LOCKWASHER	6		
10	13	32993	LOCKWASHER	2		
11	11	29553	NUT	2		
12		66166A	4 TRUNNION	4		
13	13	68102	LOCKWASHER	4		
14		66284A	2 BASE ASSEMBLY	2	ENGINE	
15	11	20739	JAM NUT	2	ENGINE	
16	14	66658	TAB WASHER	2	ENGINE	
17		816326A	2 BASE ASSEMBLY	2	TRANSMISSION	
18	11	816331	NUT	2	TRANSMISSION	
19	14	66658	TAB WASHER	2	TRANSMISSION	
20	11	20739	JAM NUT	4		
21	54	78945	CLAMP	1		