



4306

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		853437A 1	HOUSING, Flywheel	1		
2		865330A02	MOUNT KIT, Rubber	1		
3	23	99322	SPACER	2		
4		853441	COVER	1		
5		853440	PLATE, Cover	1		
6	10	853421	SCREW, (M12 x 90)	4		
7	10	40097 60	SCREW, (M12 x 60)	2		
8	12	853239	WASHER	2		
9	16	806309	STUD	2		
10	12	20572	WASHER, (.390 x .750 x .093)	2		
11	84	62826A 6	CABLE ASSEMBLY, Ground - Blac	1		
12	11	32219	NUT, (.375-16)	2		
13		853453T	MOUNT, Port	1		
14		853472A 1	MOUNT, Starboard	1		
15	10	853448	SCREW, (M12 x 30)	6		
16		853433T 1	MOUNT, Engine	2		
17	14	12657	TAB WASHER	2		
18	11	853434	NUT	2		
19	50	805833T	STARTER ASSEMBLY	1		
20	13	40024 8	LOCKWASHER, (M10)	1		
21	11	805794	NUT, (M10)	1		
22	10	40108 30	SCREW, (M10 x 15)	3		
23		805694	PICK-UP, Magnetic	1		
24	11	859126	NUT, (.750-16)	1		
25	10	853442	SCREW, (M8 x 16)	3		