



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		89011A 8	EXHAUST MANIFOLD ASSEMBLY	2		
2	16	49545	STUD, EXHAUST MANIFOLD TI	4		
3	22	33198A 1	PLUG, EXHAUST MANIFOLD	4		
4	22	73379	PLUG, PIPE-EXHAUST MANIFO	4		
5	27	46820	GASKET, EXHAUST MANIFOLD T	2		4
6	10	37612	SCREW, EXHAUST MANIFOLD (1	4		
6	10	48424	SCREW, EXHAUST MANIFOLD (1	8		
7	16	49545	STUD, EXHAUST MANIFOLD	4		
8	11	20553	NUT, EXHAUST MANIFOLD STUC	4		
9	12	20553	WASHER, EXHAUST MANIFOLD	16		
10	22	87238	DRAIN COCK, EXHAUST MANIFO	2		
11	22	36305	ELBOW, EXHAUST MANIFOLD (9	2		
12	27	87105	GASKET, ELBOW	2		4
14		44194	ADAPTOR, EXHAUST ELBOW	2		
15	16	93431	STUD, ADAPTOR TO EXHAUST E	2		4
15	16	57981	STUD, ADAPTOR TO EXHAUST E	2		
16	10	60992	SCREW, ADAPTOR	4		
17		72963A 7	EXHAUST ELBOW ASSEMBLY (P	1		
17		72963A 8	EXHAUST ELBOW ASSEMBLY (	1		
18	22	32802	PLUG, PIPE-EXHAUST ELBOW	2		
19	32	58616A 2	TUBE, WATER SEPARATION	2		
20	22	36305	FITTING, EXHAUST ELBOW (90	2		
21	13	35048	LOCKWASHER, EXHAUST MANIF	8		
22	11	49838	NUT, EXHAUST MANIFOLD STUC	8		