



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	10	60179	SCREW, TRANSMISSIN TO ENGI	6		
2	13	32993	LOCKWASHER, TRANSMISSION	6		
3	87	88031	SWITCH, TEMPERATURE	1		
4	16	87163	STUD, SHIFT CRANK TO TAILSTI	1		
5	23	26954	BUSHING, SHIFT CRANK STUD	2		
6		98301A 3	SHIFT CRANK ASSEMBLY	1		
7	16	72809	STUD, SHIFT CRANK	1		
8	12	69056	WASHER, SHIFT CRANK STUD	3		
9	11	35888	NUT, SHIFT CRANK STUD	1		
10	12	34931	WASHER, SHIFT CRANK STUD	1		
11	11	34932	NUT, SHIFT CRANK STUD	1		
12		98299A 2	SHIFT ROD ASSEMBLY	1		
13		73393	BALL JOINT	2		
14	11	25168	LOCKNUT, SHIFT ROD	2		
15		43325	LEVER, SHIFT-TRANSMISSION	1		
16	12	29245	WASHER, SHIFT ROD	1		
17	11	35888	NUT, SHIFT ROD	1		
18	12	20722	WASHER, SHIFT LEVER TO TRA	1		
19	13	26933	LOCKWASHER, SHIFT LEVER TC	1		
20	11	20083	NUT, SHIFT LEVER TO TRANSMI	1		