



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		56717	PANEL, ELECTRIC	1		
2	19	32298	PLUG, ELECTRIC PANEL	2		
3		47763	BRACKET, RETAINER - HIGH TENS	4		
4	25	38930	GROMMET, HIGH TENSION LEAD	4		
5	10	27165	SCREW, RETAINER BRACKET TO	1		
6	13	35048	LOCKWASHER, RETAINER BRAC	1		
5	10	33212	SCREW, RETAINER BRACKET TO	1		
6	13	32993	LOCKWASHER, RETAINER BRAC	1		
7	25	57009	GROMMET, ELECTRIC PANEL - T	1		
8		25661	STARTER SOLENOID	1		
9	13	26993	LOCKWASHER, STARTER SOLE	2		
10	11	20083	NUT, STARTER SOLENOID TERM	2		
11	13	26996	LOCKWASHER, STARTER SOLE	2		
12	11	20645	NUT, STARTER SOLENOID TERM	2		
13	10	26774	SCREW, STARTER SOLENOID TI	2		
14	13	26992	LOCKWASHER, STARTER SOLE	2		
15	10	26632	SCREW, ELECTRIC PANEL TO C	1		
16	10	35787	SCREW, ELECTRIC PANEL TO C	1		
17	10	47954	SCREW, ELECTRIC PANEL TO FL	1		
18	13	35048	LOCKWASHER, ELECTRIC PANE	3		
19	12	20553	WASHER, ELECTRIC PANEL SCF	3		
20	25	47624	GROMMET, ELECTRIC PANEL	1		
21	332	2986A 8	SWITCH BOX ASSEMBLY	1		
22	12	45075	WASHER, SWITCH BOX TERMIN	7		
23	13	26996	LOCKWASHER, SWITCH BOX TE	7		
24	11	45076	NUT, SWITCH BOX TERMINAL	7		
25	10	26184	SCREW, SWITCH BOX TO ELECT	4		
26	13	21547	LOCKWASHER, SWITCH BOX SC	4		
27	10	45218	SCREW, GROUND WIRE TO SWI	1		
28	322	2983A 6	IGNITION COIL ASSEMBLY	1		
29	10	45102	SCREW, IGNITION COIL CLAMP	1		
29	10	45103	SCREW, IGNITION COIL CLAMP	1		
30	12	37407	WASHER, IGNITION COIL SCRE	1		
31	54	22740	CLIP, IGNITION COIL LEAD	1		
32		22789	"D" WASHER, IGNITION COIL SC	1		
33	11	20645	NUT, IGNITION COIL SCREW	2		
34	10	26889	SCREW, IGNITION COIL TO ELEC	2		
35	13	26992	LOCKWASHER, IGNITION COIL S	2		
36	37	56428	DECAL, WIRING	1		
37		38371	SEAL, COVER TO ELECTRIC PAN	1		
38		47550	COVER, ELECTRIC PANEL	1		