



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47735A	EXHAUST MANIFOLD ASSEMBLY	1		
1		47736A	EXHAUST MANIFOLD ASSEMBLY	1		
1	16	52988	STUD, EXHAUST MANIFOLD TI	8		
3	22	48118	PLUG, EXHAUST MANIFOLD	6		
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2		
5	10	37612	SCREW, EXHAUST MANIFOLD TI	8		
5	10	26486	SCREW, EXHAUST MANIFOLD TI	8		
6	27	46820	GASKET, EXHAUST MANIFOLD T	2		
7		54870	END CAP, EXHAUST MANIFOLD I	2		
8	27	48043	GASKET, END CAP TO EXHAUST	4		
9	10	25038	SCREW, END CAP TO EXHAUST	8		
10		48101A	EXHAUST ELBOW ASSEMBLY	2		
11	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
12	32	49705	TUBE, WATER - EXHAUST ELB	2		
13	22	48118	PLUG, EXHAUST ELBOW	8		
14	27	48042	GASKET, EXHAUST ELBOW TO E	4		
15	13	37459	LOCKWASHER, EXHAUST ELBO	8		
16	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
17		57115	THERMOSTAT HOUSING	1		
18	27	48818	GASKET, THERMOSTAT HOUSIN	1		
19		35884	THERMOSTAT	1		
20	27	47510	GASKET, THERMOSTAT (MIDDLE	1		
21	23	47508	SLEEVE, THERMOSTAT HOUSIN	1		
22	27	53045	GASKET, THERMOSTAT HOUSIN	1		