



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		58036A	RESISTOR ASSEMBLY, WATER	1		
2		45315	TERMINAL BLOCK	1		
3	10	30009	SCREW, RESISTOR TO TERMII	1		
4	22	20445	FITTING, AIR BLEED HOSE TO R	1		
5	32	57130	HOSE, AIR BLEED (6 1/2")	1		
6	54	20387	CLAMP, FITTINGS TO AIR BLEED	2		
7	22	54139	FITTING, AIR BLEED HOSE TO TI	1		
8		57126	COVER, THERMOSTAT	1		
9	10	35785	SCREW, THERMOSTAT COVER	2	(3 1/4")	
10	13	37459	LOCKWASHER, THERMOSTAT C	2		
11	12	30771	WASHER, FIBER - THERMOSTAT	2		
12	12	20084	WASHER, THERMOSTAT COVEF	2		
13	13	39107	LOCKWASHER, THERMOSTAT C	2		
14	11	35814	NUT, THERMOSTAT COVER TO I	2		
15	32	35100A	HOSE, THERMOSTAT COVER TC	2		
16	54	32880	CLAMP, HOSE ATTACHING	4		
17		52884A	HOUSING ASSEMBLY, WATER D	1		
18		52885A	HOUSING ASSEMBLY, WATER D	1		
19	22	32802	PLUG, PIPE - WATER DISTRIBL	2		
20	23	52020	SLEEVE, WATER DISTRIBUTIO	4		
21	22	55133	TEE, FITTING	1		
22	32	35100A	HOSE, WATER DISTRIBUTION H	1		
23	32	35100A	HOSE, WATER DISTRIBUTION H	1		
24	54	32880	CLAMP, HOSE ATTACHING	4		
25	32	55483	HOSE, HEAT EXCHANGER END (1		
26	54	32780	CLAMP, HOSE ATTACHING	2		