



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A	FLYWHEEL HOUSING	1		
2		99297A	RUBBER MOUNT	2		
3	23	99322	SPACER	2		
4	10	37612	SCREW (1-1/4")	4		
4	10	64900	SCREW (2")	1		
5	16	64066	STUD (2-1/4")	1		
6	11	32219	NUT	1		
7	13	35048	LOCKWASHER	7		
8	12	20572	WASHER	1		
9		818719A	COVER	1		
10	10	32773	SCREW	7		
11	84	62826A	WIRE	1		