



| Parts List | | | | | |
|------------|-------|-----------|-------------------------------|-----|----------|
| Ref | Class | Part | Description | Qty | Footnote |
| 1 | | 805185A37 | DISTRIBUTOR ASSEMBLY | 1 | |
| 2 | | 815407A 2 | CAP-DISTRIBUTOR | 1 | |
| 3 | 10 | 90926 | SCREW (#10-32 X 13/16 IN.) | 4 | |
| 4 | 27 | 805760 | GASKET | 1 | |
| 5 | | 13524A 6 | ROTOR/SENSOR WHEEL | 1 | |
| 6 | 87 | 861780A 2 | SENSOR ASSEMBLY | 1 | |
| 7 | 10 | 66686 | SCREW (#10-32 X 1 IN.) | 1 | |
| 7 | 10 | 72202 | SCREW (#10-32 X 1-1/4 IN.) | 1 | |
| 8 | 13 | 26996 | LOCKWASHER (#10) | 2 | |
| 9 | 43 | 818807 | DRIVE GEAR | 1 | |
| 10 | 17 | 47617 | PIN | 1 | |
| 11 | 12 | 90931 | WASHER | 1 | |
| 12 | 27 | 34486 3 | GASKET | 1 | 5 |
| 13 | | 52185 | CLAMP | 1 | |
| 14 | 10 | 806681 | SCREW (3/8-16 X 7/8 IN.) | 1 | |
| 15 | 84 | 816761A16 | CABLE KIT-IGNITION (SPARK PLL | 1 | |
| 16 | 85 | 63709A 1 | BOOT KIT | 8 | |
| 17 | 33 | 816336 | SPARK PLUG | 8 | |
| 18 | 392 | 805570A 2 | COIL-IGNITION | 1 | |
| 19 | | 65970T 1 | BRACKET-COIL | 1 | |
| 20 | 10 | 41408 | SCREW (#10-32 X 1-1/2 IN.) | 1 | |
| 21 | 13 | 26996 | LOCKWASHER (#10) | 2 | |
| 22 | 11 | 68219 | NUT (#10-32) | 2 | |
| 23 | 10 | 98261 | SCREW (3/8-16 X 3/4 IN.) | 1 | |
| 24 | 12 | 20553 | WASHER | 1 | |
| 25 | 16 | 90096A 1 | STUD ASSEMBLY | 2 | |
| 26 | 54 | 72821 | RETAINER | 2 | |
| - | 27 | 824326A96 | GASKET SET-OVERHAUL | 1 | |