



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1		862737	HOUSING, Flywheel	1		
2		862833	BEARING, Adaptor	1		
3	22	74036	FITTING, Grease	1		
4	30	62780T	BEARING, Ball	1		
5	53	94104	RING, Retaining	1		
6		93906A 2	SHAFT, Output	1		
7	25	29845	O-RING, (.924 x .103)	2		
8	53	841897T	RING, Retaining	1		
9		93918A 1	SHIELD ASSEMBLY, Lower	1		
10	10	96995	SCREW, (.375-16 x .880)	3		
11		93919A 1	SHIELD ASSEMBLY, Upper	1		
12	10	96995	SCREW, (.375-16 x .880)	4		
13	11	826709 12	NUT, (.375-16)	4		
14	10	47651	SCREW, (.437-14 x 1.50)	4		
15	13	32993	LOCKWASHER, (.437)	4		
16		862738	BRACKET, Flywheel Housing	2		
17	10	37612	SCREW, (.375-16 x 1.250)	1		
17	10	34353	SCREW, (.375-16 x 1.00)	1		
17	10	47688	SCREW, (.375-16 x 2.750)	2		
18		66284A 2	BASE ASSEMBLY, Mount Assembl	2		
19	11	816331	NUT, (.750-16), Jam	1		
20	14	12657	TAB WASHER, Tab	1		
21	13	68102	LOCKWASHER, (.750)	2		
22	11	859126	NUT, (.750-16)	1		
23		862838	DRIVE PLATE	1		
24	10	14883	SCREW, (.375-16 x 1.12)	6		
25	13	20572	LOCKWASHER	6		
26	23	862834	BUSHING, Pilot	1		
27		817416A 4	HOUSING ASSEMBLY, Bearing	1		
28	30	93944A 2	BEARING SET, Ball, Includes Pa	1		
29	23	817417T	SPACER	1		
30	53	93914	RING, Retaining	1		
31	53	93915	RING, Retaining	1		
32	26	93924	SEAL, Oil	1		
33	22	74036	FITTING, Grease	2		
34		NSS	NOT SOLD SEPARATE, Shaft-In	1		
35	19	93921	EXPANSION PLUG	1		
36		93918A 1	SHIELD ASSEMBLY, Lower	1		
37	10	76926	SCREW, (.375-16 x .875)	3		
38		93919A 1	SHIELD ASSEMBLY, Upper	1		
39	10	96995	SCREW, (.375-16 x .880)	4		