



18349

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		864592T	HOUSING ASSEMBLY, Thermosta	1	(Standard Cooling)	
2	22	32803	PLUG, Pipe - Brass (.375-18)	2		
3		806490T	SENDER	1		
3		49734	SENDER, Dual Station	OPT		
4	13	26996	LOCKWASHER, (#10)	1		
5	11	68219	NUT, (#10-32)	1		
6		805218T	SENSOR	1		
7	27	806871	GASKET, Thermostat Housing	1		2
8		807252T 2	THERMOSTAT, 160 Degrees	1		
9	23	806922	SLEEVE, Thermostat	1		
10	27	53045 1	GASKET, Lower Thermostat Housir	1		2
11	10	98508	SCREW, (.375-16 x 3.00)	2		
12		12552	LIFTING EYE	1		
13	22	98477A 2	VALVE ASSEMBLY, Tee	1		
14	30	98475	BALL, Nylon	2		
15	24	75533	SPRING	2		
16	12	89302	WASHER, (.203 x .406 x .040)	2		
17	10	98476	SCREW, (#10-32 x 6.00)	1		
18	11	826709106	NUT, (#10-32)	1		
19		864398T1	HOUSING ASSEMBLY, Thermosta	1	(Closed Cooling)	
20	27	53045 1	GASKET, Thermostat Housing	2		2
21	22	32803	PLUG, Pipe - Brass (.375-18)	2		
22	25	807134 1	SEAL, Thermostat	1		2
23	10	68101	SCREW, (.375-16 x 1.375)	2		
24		805218T	SENSOR	1		
25		806490T	SENDER, Coolant Temperature	1		
25		49734	SENDER	OPT	(Dual Station)	
26	13	26996	LOCKWASHER, (#10)	1		
27	11	68219	NUT, (#10-32)	1		
28		864493	THERMOSTAT, (170 Degree F)	1		
29		807075A 1	COVER, Thermostat	1		
30	22	818390	DRAIN COCK	1		
31	10	29198	SCREW AND LOCKWASHER, (.31	2		
32	20	865525	VALVE	1		