



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	808045	HOSE, Fuel Cooler to Transmission	1		
2		861505	FITTING, Drain Assembly	1		
3	22	806608A.1	PLUG KIT, Blue	1		
4	25	32509	O-RING, (.489 x .070), Drain Plug	1		
5	32	860332001	HOSE, Drain Fitting to Heat Exchar	1		
6	32	864713	HOSE, Thermostat Housing to Upp	1	(Without Riser)	
6	32	865532	HOSE, Thermostat Housing to Upp	1	(With Riser)	
7	32	864714	HOSE, Thermostat Housing to Upp	1	(Without Riser)	
7	32	33220 70	HOSE, (48.00 Inches Bulk), Therm	1	(With Riser) (Cut to Fit)	
8	32	865531	HOSE, Thermostat Housing to Low	1	(Starboard)	
9	32	865530	HOSE, Thermostat Housing to Low	1	(Port)	
10	32	865529	HOSE, Intake Bypass to Circulating	1		
11	32	864436	HOSE, Heat Exchanger to Thermo:	1		
12	32	864437	HOSE, Heat Exchanger to Thermo:	1		
13	32	864532	HOSE, Heat Exchanger to Starboa	1	(Without Riser)	
13	32	864934	HOSE, Heat Exchanger to Starboa	1	(With Riser)	
14	32	864726	HOSE, Heat Exchanger to Port Elb	1	(Without Riser)	
14	32	864932	HOSE, Heat Exchanger to Port Elb	1	(With Riser)	
15	32	863611 1	Hose, Sea Pump to Power Steering	1		
16	54	815504212	CLAMP, Worm Gear, Hose	2		
17	54	815504216	CLAMP, Worm Gear, Hose	AR		
18	54	815504222	CLAMP, Worm Gear, Hose	AR		
19	54	815504228	CLAMP, Worm Gear, Hose	AR		
20	54	815504232	CLAMP, Worm Gear, Hose	AR		
21	32	864886	HOSE, Heat Exchanger to Circulat	1		
22	54	815504224	CLAMP, Worm Gear, Hose	AR		
23		864395T01	HEAT EXCHANGER, Closed Coolir	1		
24		814875	COVER, Heat Exchanger End	2		
25	27	803644	GASKET, End Cover	2		
26	10	814877	BOLT	2		
27	25	814878	O-RING, Special	2		
28	36	814879 1	CAP, Pressure	1		
29	10	805559	SCREW, (.375-16 x .875)	1		
30	10	34353	SCREW, (.375-16 x 1.00)	1		
31	54	815504396	CLAMP, Worm Gear, Heat Exchang	2		
32		71587A10	COOLANT RECOVERY KIT	1		
33		71587A11	BOTTLE, Coolant Recovery Kit	1		
34		72058	CAP, Coolant Recovery Bottle	1		
35	32	863343 79	HOSE, (96 Inch Bulk), Sea Water F	1		
36		18431	PAD, Heat Exchanger	1		
37		864405T	BRACKET, Cooler	1		