



1786

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		860234A	1 HEAT EXCHANGER	1		
NS		814875	COVER, Heat Exchanger End	2		
NS	27	803644	GASKET	2		
NS	10	814877	BOLT	2		
NS	25	814878	O-RING, (Special)	2		
NS	36	814879	CAP	1		
2		860326A	2 BRACKET ASSEMBLY, Heat Exch	1		
3		18431	PAD	2		
4	54	815504388	CLAMP, Worm Gear	2		
5		71587A10	COOLANT RECOVERY KIT	1	(SEE NOTE)	
6		71587A11	BOTTLE	1		
7		72058	CAP	1		
8		861198A	1 HOUSING, Thermostat	1		
9	25	807134	1 SEAL	1		3
10	23	52020	SLEEVE, Hose	1		
11	22	32803	PLUG, Pipe (.375-18 Brass)	1		
12		99155	1 THERMOSTAT	1		
13		807075A	1 COVER	1		
14	10	29198	SCREW AND LOCKWASHER, (.31	2		
15	10	58640	SCREW, (.375-16 x 1.25)	2		
16	22	32802	2 PLUG, Pipe (.125-27) Brass	1		
17	27	53045	1 GASKET	2		3
18	32	42850	69 HOSE, (.44.00 Inches Bulk)	1		
19	32	860327	HOSE	1	(STARBOARD)(2 PC MANIFOLD)	
19	32	860421	HOSE, Heat Exchanger To Exhaus	1	(STARBOARD)(1 PC MANIFOLD)	
20	32	862150	HOSE, Heat Exchange To Exhaust	1	(PORT)(2 PC MANIFOLD)	
20	32	862125	HOSE, Heat Exchanger To Exhaus	1	(PORT)(1 PC MANIFOLD)	
21	54	815504220	CLAMP, Worm Gear	6		
22	32	860485	HOSE, Thermostat By-Pass	1		
23	32	860419	HOSE, Thermostat Housing To Hex	1		
24	32	860332	HOSE, Oil Cooler To Heat Exchang	1		
25	54	815504222	CLAMP, Worm Gear	6		
26	32	861059	HOSE	1		
27	54	815504232	CLAMP, Worm Gear	2		
28	32	805987	1 HOSE, Water Pump To Intake Mar	1		
29	54	815504228	CLAMP, Worm Gear	2		
30	22	860346	ELBOW, (.750)	1		
31	22	806242	CONNECTOR (1/2-14)	1		
32		860315A	1 TUBE, Hose Extender	1		
33		860418T	BRACKET	1		
34		860417T	CLAMP	1		