



A= See "Alternator and Bracket" Section



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		16792A39	PUMP ASSEMBLY-POWER STEE	1		
2	16	41877	STUD	2		
3	36	95805	CAP	1		
4		861578	PULLEY (5-3/4" METAL)	1		1
5		807751T	BRACE	1		
6	10	40001188	SCREW (M10 X 20)	3		
7	12	34714	WASHER	3		1
8	11	32219	NUT (3/8-16)	3		
9	23	90520 1	SPACER	1		
10	11	90517	NUT	1		
11	32	806222 16	PRESSURE HOSE	1	(SEE ILLUSTRATION)	
11	32	862878	PRESSURE HOSE	1	(SEE ILLUSTRATION)	
12	25	89879	O-RING	1		
13	25	806232	O-RING	1		
14	32	806221 42	RETURN HOSE	1	(FITTING ON ONE END)	
15	25	89879	O-RING	1		
16	32	52519 14	HOSE-PUMP TO OIL COOLER	1		
17	54	815504105	CLAMP	3		
NS	19	807992 1	COVER-HOSE CLAMP END	AR		