



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	863489	HOSE, Power Steering Cooler to Cr	1		
2	21	864206A	CHECK VALVE ASSEMBLY	1		
3	32	863811	HOSE, Check Valve to Fuel Cooler	1		
4	32	863456A	HOSE ASSEMBLY, Thermostat Ho	1		
5		863841T	WATER TUBE, Brass	1	(Compact Hydraulic Steering)	
6	32	863343	HOSE, Sea Water Pump to Water F	1		
7	32	863458	HOSE, Thermostat Housing to Port I	1		
8	32	863858	HOSE, Thermostat Housing to Star	1		
9	32	807661	HOSE, Transom to Power Steering	1		
10	32	863781	HOSE, Fuel Cooler to Water Distrib	1		
11	22	864621A	FITTING ASSEMBLY, Lower Distrib	1		
12	25	62702	O-RING, (.301 x .070)	2		
13	32	863490	HOSE, Water Drain Accumulator to	1		
14	32	863491	HOSE, Distribution Fitting to "Y" Fit	1		
15	32	42850	HOSE, (44.00 Inches Bulk), Starbo.	1	(Cut to 22 Inch Length)	
16	32	42850	HOSE, (44.00 Inches Bulk), Port M.	1	(Cut to 29 Inch Length)	
17	32	862317	HOSE, Cylinder Block Drain to Distr	2	(Port-23 Inch) (Starboard-17 Inch)	
18	22	862225	FITTING, Pushlock	2		
19	32	863465	HOSE, Drain Accumulator to Tee F	1		
20	22	863464	FITTING, Tee	1	(Bravo Only)	
20	22	863464A	FITTING	1	(Alpha Only)	
NS	23	864327	BUSHING, Orifice	1	(Alpha Only)	
NS	25	864353	O-RING	1	(Alpha Only)	
21	32	864560	HOSE, Fitting to Port Elbow	1	(Without Riser)	
21	32	864962	HOSE, T, Fitting to Port Elbow	1	(With Riser)	
22	32	864711	HOSE, T, Fitting to Starboard Elbow	1	(Without Riser)	
22	32	864963	HOSE, T, Fitting to Starboard Elbow	1	(With Riser)	
23	32	863611	HOSE, Sea Water Pump to Power	1	(Cut To Length)	
24	54	815504212	CLAMP, Worm Gear - SS, Hose	2		
25	54	815504216	CLAMP, Worm Gear, Hose	AR		
26	54	815504222	CLAMP, Worm Gear, Hose	AR		
27	54	815504228	CLAMP, Worm Gear, Hose	1		
28	54	815504232	CLAMP, Hose	AR		
29	22	862603	FITTING, Male Quick Connector (T	2		
NS	19	807992	COVER, Hose Clamp End	AR		