



2215

| Parts List | | | | | | |
|------------|-------|-----------|----------------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 26079A 2 | PLATE KIT, Wire Harness Mount | 1 | | |
| 2 | 10 | 15001 | SCREW, (#8-16 x .875) | 3 | | |
| 3 | | 863440T | BRACKET, Harness Mounting/Lift | 1 | | |
| 4 | 10 | 98261 | SCREW, (.375-16 x .750) | 2 | | |
| 5 | | 865830T02 | MODULE ASSEMBLY, ECM | 1 | (Alpha-Standard Cooling) | |
| 5 | | 865831T02 | MODULE ASSEMBLY, ECM | 1 | (Alpha-Closed Cooling) | |
| 5 | | 865832T01 | MODULE ASSEMBLY, ECM | 1 | (Bravo-Standard Cooling) | |
| 5 | | 865833T01 | MODULE ASSEMBLY, ECM | 1 | (Bravo-Closed Cooling) | |
| 6 | 10 | 821300 25 | SCREW, (M6 x 25) | 3 | | |
| 7 | 12 | 65567 | WASHER, (.265 x .750 x .048) | 3 | | |
| 8 | 25 | 834985 | GROMMET | 3 | | |
| 9 | 23 | 856954 | BUSHING | 3 | | |
| 10 | | 863424T | BRACKET | 1 | | |
| 11 | 10 | 860008 | SCREW, Torx (.250-20 x .625) | 3 | | |
| 12 | 84 | 865456A01 | WIRING HARNESS | 1 | | |
| 13 | 54 | 804351 | CLIP, Relay Mounting | 2 | | |
| 14 | 54 | 804352 | CLIP, Fuse Block Mounting | 1 | | |
| 15 | | 883562 | COVER, Fuse | 1 | | |
| 16 | | 865202T | RELAY | 1 | | |
| 17 | 88 | 832969 20 | FUSE, Yellow - 20 Ampere | 3 | | |
| 18 | | 805368T | BRACKET, Electrical, Mounting | 1 | | |
| 19 | 88 | 806950 | CIRCUIT BREAKER, (50 Ampere) | 1 | | |
| 20 | 13 | 26996 | LOCKWASHER, (#10) | 2 | | |
| 21 | 10 | 68513 | SCREW, (#10-32 x .375) | 2 | | |
| 22 | 10 | 57583 | SCREW, (#8-32 x .375) | 2 | | |
| 23 | 89 | 96158T | SOLENOID, Starter | 1 | | |
| 24 | 13 | 26992 | LOCKWASHER, (.250) | 2 | | |
| 25 | 11 | 26419 | NUT, (#8-32) | 2 | | |
| 26 | 10 | 805564 | SCREW, (.250-20 x .750) | 1 | | |
| 27 | 13 | 26995 | LOCKWASHER, (#8) | 2 | | |
| 28 | 11 | 26419 | NUT, (#8-32) | 2 | | |
| 29 | 85 | 97861 | INSULATOR, Starter Solenoid | 1 | | |
| 30 | | 816492A15 | ALARM KIT | 1 | | |
| 31 | 84 | 95084A 9 | CABLE ASSEMBLY, (91.00 Inches) | 1 | | |
| 32 | 88 | 79091 | FUSE, 20 Ampere | 1 | | |
| 33 | 84 | 95084A10 | CABLE ASSEMBLY, (5.00 Inches) | 1 | | |
| 34 | | 864337A 1 | CONNECTOR, Bravo Shift Interrupt | 1 | (Black Wire) | |
| 35 | 87 | 815425T | SENDER ASSEMBLY, Oil | 1 | | |
| 35 | | 37293T | SENDER ASSEMBLY, Oil | 1 | (Dual Station) | |
| 36 | | 881879 3 | SENSOR, Pressure | 1 | (Power Steering Cooler) | |
| 36 | | 881879A 2 | SENSOR KIT, (100 PSI) | 1 | (Oil) | |