



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		862737	HOUSING, Flywheel	1	
2		862833	BEARING, Adaptor	1	
3	22	74036	FITTING, Grease	1	
4	30	62780T	BEARING, Ball	1	
5	53	94104	RING, Retaining	1	
6		93906A 2	SHAFT, Output	1	
7	25	29845	O-RING, (.924 x .103)	2	
8	53	841897T	RING, Retaining	1	
9		93918A 1	SHIELD ASSEMBLY, Lower	1	
10	10	96995	SCREW, (.375-16 x .880)	3	
11		93919A 1	SHIELD ASSEMBLY, Upper	1	
12	10	96995	SCREW, (.375-16 x .880)	4	
13	11	826709 12	NUT, (.375-16)	4	
14	10	47651	SCREW, (.437-14 x 1.50)	4	
15	13	32993	LOCKWASHER, (.437)	4	
16		862738	BRACKET, Flywheel Housing	2	
17	10	37612	SCREW, (.375-16 x 1.250)	1	
17	10	34353	SCREW, (.375-16 x 1.00)	1	
17	10	47688	SCREW, (.375-16 x 2.750)	2	
18		66284A 2	BASE ASSEMBLY	2	
19	11	816331	NUT, (.750-16), Jam	1	
20	14	12657	TAB WASHER, Tab	1	
21	13	68102	LOCKWASHER, (.750)	2	
22	11	859126	NUT, (.750-16)	1	
23		862838	DRIVE PLATE	1	
24	10	14883	SCREW, (.375-16 x 1.12)	6	
25	12	20572	WASHER, (.390 x .750 x .093)	6	
26	23	862834	BUSHING, Pilot	1	
27		817416A 4	HOUSING ASSEMBLY, Bearing	1	
28	30	93944A 2	BEARING SET, Ball	1	
29	23	817417T	SPACER	1	
30	53	93914	RING, Retaining	1	
31	53	93915	RING, Retaining	1	
32	26	93924	SEAL, Oil	1	
33	22	74036	FITTING, Grease	2	
34		NSS	NOT SOLD SEPARATE, Shaft-In	1	
35	19	93921	EXPANSION PLUG	1	
36		93918A 1	SHIELD ASSEMBLY, Lower	1	
37	10	76926	SCREW, (.375-16 x .875)	3	
38		93919A 1	SHIELD ASSEMBLY, Upper	1	
39	10	96995	SCREW, (.375-16 x .880)	4	