



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		862031T	ALTERNATOR ASSEMBLY (65 A	1	[w/62 MM Pulley](0M320024 and	1
1		863077T	ALTERNATOR ASSEMBLY (65 A	1	[with 50mm Pulley](SN-0M320025	
2	11	40021	NUT	1		
3	10	40001134	SCREW	1		
4	10	828213	SCREW	2		
5	12	57792	WASHER	2		
6	11	26484	NUT	2		
7		862055T	BRACKET-ALTERNATOR MOUNT	1		1
8	10	98261	SCREW	3		
9		860065A	BRACKET-RESERVOIR MOUNTIN	1		
10	10	98261	SCREW	6		
11	11	32219	NUT	2		
12		862056T	BRACKET	1		
13		862083T	BRACKET-IDLER ADJUSTING	1		
14		818380T	BUSHING	1		
15	11	859135	NUT	1		
16	43	818381	PINION STUD	1		
17		807757T	PULLEY	1	(3 IN. DIA.)(S/N-0M320024 and B	
17		864625T	PULLEY	1	(4-1/4 IN. DIA.)(S/N-0M320025 ar	
17		807757T	PULLEY	1	(3 IN. DIA.)(S/N-0M320025 and U	
18	10	34353	SCREW	2		
19		862082T	BRACKET-POWER STEERING BF	1		1
20	10	40001188	SCREW	1		
21		862778A	BRACKET-ALTERNATOR BRACE	1	(ALPHA)	1
22	11	29250	NUT	1		
23		862084T	BRACKET-ILDER	1		1
24	11	32219	NUT	2		
25		862085T	BRACKET-ILDER BRACE	1		1
26	16	860102	STUD	2	(BRAVO)	
27		818382	PULLEY	1		
28		818380T	BUSHING	1		
29	10	56393	SCREW	1		
30	11	859135	NUT	1		