



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		805185A27	DISTRIBUTOR ASSEMBLY	1	
2		815407A 2	CAP	1	
3	10	90926	SCREW (#10-32 x 13/16 in.)	4	
4	27	805760	GASKET	1	
5		13524A 6	ROTOR/SENSOR WHEEL	1	
6	87	91019A 6	SENSOR ASSEMBLY	1	
7	10	66686	SCREW (#10-32 x 1 in.)	1	
7	10	72202	SCREW (#10-32 x 1-1/4 in.)	1	
8	43	818807	DRIVE GEAR	1	
9	17	47617	PIN	1	
10	12	90931	WASHER	1	
11	27	34486 3	GASKET	1	2
12		52185	CLAMP	1	
13	10	806681	SCREW (3/8-16 x 7/8 in.)	1	
14	84	816761A16	CABLE KIT-Ignition (Spark Plug & C	1	
15	85	63709A 1	BOOT	8	
16	33	59571	SPARK PLUG	8	
17	392	805570A 2	COIL-Ignition	1	
18		65970T 1	BRACKET	1	
19	10	41408	SCREW (#10-32 x 1-1/2 in.)	1	
20	13	26996	LOCKWASHER (#10)	2	
21	11	68219	NUT (#10-32)	2	
22	10	98261	SCREW (3/8-16 x 3/4 in.)	1	
23	12	20553	WASHER	1	
24	16	90096A 1	STUD ASSEMBLY	2	
25	54	72821	RETAINER	2	