



A = SEE "STARTER MOTOR AND ALTERNATOR" REF. #17

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		16792A39	PUMP ASSEMBLY-POWER STEE	1		
2	16	41877	STUD	2		
3	36	95805	CAP	1		
4	57	861758A 1	BELT/PULLEY KIT	1	(ALPHA) 4-3/4 IN. DIA. PULLEY	
4	57	861759A 1	BELT/PULLEY KIT	1	(BRAVO) 4-3/4 IN. DIA. PULLEY	
4		861578	PULLEY	1	(5-3/4 IN. DIA. PULLEY)	
5		807751T	BRACE	1		
6	10	40001188	SCREW (M10 X 20)	3		
7	11	32219	NUT (3/8-16)	3		
8	23	90520 1	SPACER	1		
9	11	90517	NUT	1		
10	32	806222 16	PRESSURE HOSE	1	(FITTINGS ON BOTH ENDS)	
11	25	89879	O-RING	1		
12	25	806232	O-RING	1		
13	32	806221 42	RETURN HOSE	1	(FITTING ON ONE END)	
14	25	89879	O-RING	1		
15	32	52519 14	HOSE-PUMP TO OIL COOLER	1		
16	54	815504105	CLAMP	3		