



- |  |   |
|--|---|
| 1 VAPOR SEPARATOR TANK (VST)                           | 2 THROTTLE BODY                         |
| 3 DISTRIBUTOR  | 4 COIL                                  |
| 5 ELECTRONIC SPARK CONTROL (ESC) MODULE                | 6 ASSEMBLY LINE DATA LINK (ALDL)        |
| 7 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR              | 8 MANIFOLD AIR TEMPERATURE (MAT) SENSOR |
| 9 KNOCK SENSOR   | 10 IDLE AIR CONTROL (IAC)               |
| 11 THROTTLE POSITION SENSOR (TPS)                      | 12 COOLANT TEMPERATURE SENSOR (CTS)     |
| 13 ELECTRONIC CONTROL MODULE (ECM)                     | 14 FUEL PUMP RELAY (P/N 807057)         |
| 15 SYSTEM RELAY  | 16 FUEL PUMP FUSE                       |
| 17 ECM/BATTERY FUSE                                    | 18 ECM/INJECTOR FUSE                    |
| 19 HARNESS CONNECTOR TO STARTING/CHARGING HARNESS      |   |
| 20 HARNESS CONNECTOR TO LANYARD STOP SWITCH (OPTIONAL) |   |
| 21 HARNESS CONNECTOR FOR DUAL ENGINE DATA LINK CABLE   |   |
| 22 POSITIVE (+) POWER WIRE TO ENGINE CIRCUIT BREAKER   |   |

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	84	860226A 2	WIRING HARNESS (EFI)	1		