



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		805597T	BRACKET (REAR)	2	
2	10	37269	SCREW (2")	4	
3	13	32993	LOCKWASHER	4	
4	10	57357	SCREW (2-1/4")	2	
5	13	32993	LOCKWASHER	2	
6	11	29553	NUT	2	
7		71128A	BRACKET (FRONT)	2	
8	10	68101	SCREW (1-3/8")	6	
9	13	35048	LOCKWASHER	6	
10	10	57357	SCREW	2	
11	13	32993	LOCKWASHER	2	
12	11	29553	NUT	2	
13		66166A	TRUNNION	4	
14	13	68102	LOCKWASHER	4	
15		66284A	BASE ASSEMBLY ENGINE	2	
16	11	20739	JAM NUT ENGINE	2	
17	14	66658	TAB WASHER ENGINE	2	
18		816326A	BASE ASSEMBLY TRANSMISSI	2	
19	11	816331	NUT TRANSMISSI	2	
20	14	66658	TAB WASHER TRANSMI	2	
21	11	20739	JAM NUT	4	