



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	44348	TUBE, EXHAUST	2	THRU PROP EXHAUST	
2	54	31765	CLAMP, EXHAUST BELLOWS	8	THRU PROP EXHAUST	
3		44267T	EXHAUST ELBOW ASSEMBLY	2	THRU PROP EXHAUST	
4	54	31765	CLAMP, EXHAUST TUBE	8	THRU PROP EXHAUST	
5	32	14358	EXHAUST TUBE	2	THRU PROP EXHAUST	
6		14348A	WATER SHUTTER	1	THRU PROP EXHAUST	
7		44266T	EXHAUST PIPE	1	THRU PROP EXHAUST	
8	10	58640	SCREW, EXHAUST ELBOW (1-1/4	4	THRU PROP EXHAUST	
9	13	41471	LOCKWASHER, EXHAUST ELBO\	4	THRU PROP EXHAUST	
10		97350T	PLATE	1	THRU TRANSOM EXHAUST	
11	10	98794	SCREW	4	THRU TRANSOM EXHAUST	
12	13	41471	LOCKWASHER	4	THRU TRANSOM EXHAUST	
13		78458A	EXHAUST TUBE	1	THRU TRANSOM EXHAUST	