



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		805185A26	DISTRIBUTOR	1		
2		805759A 2	CAP	1		
3	10	90926	SCREW	4		
4	27	805760	GASKET	1		
5		13524A 5	ROTOR/SENSOR WHEEL	1		
8A	87	91019A 6	SENSOR ASSEMBLY	1		
9	10	47618	SCREW	1		
10	12	27736	WASHER	2		
11	43	818807	DRIVE GEAR	1		
12	17	47617	PIN	1		
12A	12	90931	WASHER	1		
13	27	34486 3	GASKET	1		1
14		52185	CLAMP	1		
15	10	806681	SCREW	1		
20	84	816608A61	SPARK PLUG WIRE KIT	1		
22	33	59571	SPARK PLUG	8		
23		54676	RETAINER (2 WIRE)	2		
24		32783	RETAINER (3 WIRE)	2		
25		32784	RETAINER (4 WIRE)	2		
26	392	805570A 2	IGNITION COIL	1		
27		65970T 1	BRACKET	1		
28	10	41408	SCREW (1-1/2")	1		
30	13	26996	LOCKWASHER	2		
31	11	68219	NUT	2		
32	10	92913	SCREW (3/4")	2		
34	16	90096A 1	STUD ASSEMBLY	2		
35	54	72821	RETAINER	2		