



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		818383T	FUEL PUMP	1		
2	27	34213	GASKET	1		1
3	10	34354	SCREW	2		
4	13	35048	LOCKWASHER	2		
5	22	43276	FITTING (90 DEGREES)	2		
6		89876A 3	BASE ASSEMBLY	1		
7	22	32561	PIPE PLUG	3		
8	22	816133 1	FITTING	1		
9	11	29250	NUT	2		
10	35	806771	FUEL FILTER	1		
11	22	42897	FITTING (STRAIGHT)	1		
12	32	818385T	FUEL LINE-FUEL FILTER TO FUE	1		
13	32	821499T	FUEL LINE-PUMP TO CARB	1		
14	32	73815 67	HOSE-FUEL PUMP TO CARBURE	1		
15		805556T 1	BRACKET	1		